

OUTERIMPACT

Sig® M17 M.R.A. (Modular Red Dot Adapter) Mounting Instructions

- While it is possible to install this mount without the use of a Gun Smith, we recommend using a certified Gun Smith for Installation

WARNING: Never remove or install components on a gun without ensuring the gun is not loaded and the chamber is clear.

Step 1: Disassemble slide to remove rear sight plate per manufacturer's instructions taking care not to lose the Loaded Chamber Indicator or the Loaded Chamber Indicator spring.



Step 2: Place Outerimpact plate onto slide with notch for the Loaded Chamber Indicator to the front under the cut-out.

Step 3: Secure adapter plate to slide using the 4-48 screws from the bag marked MNT HDWR and torque to 15 in/lb with a torque wrench.



Step 4: Reassemble slide per manufacturer instructions.

Step 5: Using the screws/pins and the mounting pattern identified, mount the Red Dot sight adapter and torque to 12 in/lbs

| Mounting Patterns | Sight Manufacturer | Sight Models | Screws Used |
|-------------------|---------------------------------------|--|--|
| | Vortex Burris UTG TrueGlo | Viper Fast Fire 3 Reflex Micro Dot | M3 x 8 |
| | Burris Doctor Insight Eotech | Fast Fire 2 MRDS MRDS | M3 x 6 |
| | Vortex | Venom | M3 x 6 |
| | Trijicon | RMR | #6 |
| | Holosun | 507c | Additional Screw Purchase Required |
| | Leupold | Delta Point Delta Point Pro | Sight Supplied Screws work |
| | Shield | RMS | Additional Screw Purchase Required |
| | Vortex Sig Sauer CMORE | Razor Romeo 3, Max, XL RTS & STS | M4 |

Utilize liquid thread locker upon final installation of all threaded fasteners